

To see how the guidelines compare  
and check the boxes of the warrants









to other warrants, enter the chart's "selections" you want to compare to






ct data" area












Left Turn - 95% Queue Length





Right Turn - 95% Queue Length









### U Turn - 95% Queue Length








Adjusted Flowrate (vph










1)












### Turn, 10% Left Turn - 95% Queue Length





### Turn, 20% Left Turn - 95% Queue Length















Turn, 30% Left Turn - 95% Queue Length
















60% U Turn, 40% Left Turn - 95% Queue Length





50% U Turn, 50% Left Turn - 95% Queue Length















40% U Turn, 60% Left Turn - 95% Queue Length














30% U Turn, 70% Left Turn - 95% Queue Length




20% U Turn, 80% Left Turn - 95% Queue Length







### 10% U Turn, 90% Left Turn - 95% Queue Length









2000

